




K-6100

K-6100 is 5000 IN 1 universal A/C remote control. This model build-in Clock, Timer On/Off, Quickly Search, Brands Search functions. And it can directly control 4 brands A/C (MITSUBISHI GREE, MIDEA, Panasonic National) without any setup when insert batteries.

Setting Method

Turn on you're A/C, let the remote control aim the A/C receive window.




Noted: Press any key to turn on the Backlight. Only can change the state when the Backlight is on.

Method A: Quickly Input Code

1, Turn on your A/C manually, and find out your brand code from the code list. One brand may have many codes, you can choose the first set code. (if no work, then choose next set, till you find the correct code.)

2, Press "SELECT" button and "ENTER" button together, the remote control will come into setting mode, code display "----" and flash on the screen,



- Press "CODE+/- TIME+" for setting thousands digit
- Press "CODE+/- TIME+" for setting thousands digit



- Press "TIMER ON" for setting tens digit
- Press "TIMER OFF" for setting units digit



3, If the code can work well, press "ENTER" for saving code.

Remark: If there is no any operation at the remote control within 15s, it will exit setting mode and not save the code.

Method B: Manually search code

1, Let the remote control aim the A/C receive window, press "SELECT" for 3s, then the remote control will come into setting mode, and the remote control will send one code by each click on "SELECT" button, when the A/C has reaction, press "ENTER" for confirmation and saving code.




2, Let the remote control aim the A/C receive window again for testing other buttons function, if the code is invalid, make the setting again according to above method.

Remark: If there is no any operation at the remote control within 15s, it will exit setting mode and not save the code.

Method C: Quickly auto search code

1, press and hold "SELECT" button, don't release the button, the remote control will come into auto search mode, code will display "----" and flash on screen, when the A/C has reaction, release "SELECT" button at once, setting to be finished.



2, Let the remote control aim the A/C receive window again for testing other buttons function, if the code is invalid, make the setting again according to above method.

(Remark: this remote control build-in intelligent speed function. If after setting, you feel the remote control operation not so fast for A/C, you can press "ENTER" button and don't release, when the A/C has reaction, release the button, then test the remote control again.)

Method D: Brand search

press the corresponding key of brand and don't release, when the A/C has reaction, release the button at once. Test the functions are ok or not, if it is invalid, please reset again.


Remark: the screen will display the code "----" and flash when you make setting, release the button, it will display current code.

The brand list for corresponding key

1)MODE	GREE/Haier
2)SWING: AUTO	Panasonic/DAIKIN/HITACHI
3)VANE: MANUAL	SHARP/TOSHIBA/MITSUBISHI
4)FAN	SAMSUNG/LG/AUCMA
5)TEMP+	MIDEA/CHANGHONG
6)TEMP-	CHIGAO/AUX/SHINCO
7)TIMER ON	SANYO/FUJITSU/CARRIER
8)TIMER OFF	TCL/YAIR/Electrolux
9)CLOCK	GALANZ/FRESTECH/KELON
10)F.COOL	NEC/CORONA/INDIA
11)F.HEAT	KONKA/Whirlpool/Indonesia

Clock Function

Press "CLOCK" button, time will be started flashing.



Press "CLOCK" button again, time will be stopped flashing, setting to be finished. (or it will auto confirm after 8s if don't have other operation.)

Timing Function

1, press "TIME ON" button, the time of "TIME ON" will flash,



3, press "TIME OFF" button, the time of "TIME OFF" will flash,



REMARK: 1, can adjust time range: 24 hours 2, Continuously press "TIME ON" or "TIME OFF" two times, it will cancel "TIME ON" or "TIME OFF", time for "TIME ON" or "TIME OFF" will disappear from the screen. 3, after setting timing function, you need to let the remote control aim the A/C receive window, otherwise the time is invalid.

Factory reset function


1, press "SELECT" button and "FAN" button together. 2, about 5s, the whole screen will light 1s, all setting will back to factory initial mode.



K-6100

Το K-6100 είναι ένα πολυτηλεχειριστήριο για κλιματιστικά με 5000 κωδικούς. Έχει ενσωματωμένο ρολόι, χρονοδιακόπτη γρήγορη αναζήτηση, αναζήτηση με μάρκα και μπορεί να χειριστεί 4 μάρκες ταυτόχρονα χωρίς ρύθμιση (MITSUBISHI, GREE, MIDEA, PANASONIC).

Μέθοδος ρύθμισης




Πατήστε οποδήποτε πλήκτρο για να ενεργοποιηθεί ο φωτισμός


Μέθοδος ρύθμισης Α : ΜΕ ΚΩΔΙΚΟ

1) Ανοίξε το κλιματιστικό σας χειροκίνητα και βρείτε τη μάρκα στη λίστα. Μια μάρκα μπορεί να έχει πολλούς κωδικούς.

2) Πατήστε SELECT και ENTER ταυτόχρονα το Κ-6100 θα μπει στη λειτουργία προγραμματισμού και δοκιμάστε τον πρώτο κωδικό.



- Πατήστε CODE +/- TIME+ για τις χιλιάδες
- Πατήστε CODE +/- TIME+ για τις εκατοντάδες



- Πατήστε TIMER ON για τις δεκάδες
- Πατήστε TIMEROFF για τις μονάδες



3) Εάν ο κωδικός λειτουργεί σωστά πατήστε ENTER για να τον αποθηκεύσει διαφορετικά δοκιμάστε τους υπόλοιπους κωδικούς της μάρκας σας.

Μέθοδος ρύθμισης Β : ΧΕΙΡΟΚΙΝΗΤΗ ΑΝΑΖΗΤΗΣΗ

1) Εφάρσον είστε μπροστά στο κλιματιστικό πατήστε SELECT για 3 δευτερά, τότε το Κ-6100 έχει μπει σε κατάσταση προγραμματισμού.


Έπειτα πατήστε διακεκομμένα το πλήκτρο SELECT και όταν το κλιματιστικό σας ανοίξει ή να κλείσει πατήστε το πλήκτρο ENTER.



2) Σε περίπτωση που δεν λειτουργεί σωστά το Κ-6100 στο κλιματιστικό σας επαναλάβετε τη διαδικασία (1).

Μέθοδος ρύθμισης Γ : ΑΥΤΟΜΑΤΗ ΑΝΑΖΗΤΗΣΗ

1) Κρατήστε πατημένο το πλήκτρο SELECT (χωρίς να το αφήσετε) έως και 10λεπτά. Όταν ανοίξει ή κλείσει το κλιματιστικό σας αφήστε το πλήκτρο SELECT και ξαναπατήστε το μια φορά.



2) Σε περίπτωση που δεν λειτουργεί σωστά το Κ-6100 στο κλιματιστικό σας επαναλάβετε τη διαδικασία (1).

Μέθοδος ρύθμισης D : ΑΝΑΖΗΤΗΣΗ ΜΕ ΜΑΡΚΑ

1) Πατήστε το πλήκτρο που αντιστοιχεί στη μάρκα του κλιματιστικού σας παρατεταμένα και μην το αφήσετε μέχρι να ανοίξει ή να κλείσει .

Σημείωση : στην οθόνη θα εμφανιστεί ο κωδικός "----" και θα αναβοσβήνει όσο κάνετε αναζήτηση . Όταν θα απελευθερώσετε το πλήκτρο θα σας εμφανίσει τον τρέχων κωδικό .

Ρύθμιση ρολογιού

- 1) Πατήστε CLOCK και η ώρα θα αρχίσει να αναβοσβήνει .
- 2) Πατήστε TIME +/- για να ρυθμίσετε την ώρα .



Πατήστε ξανά CLOCK και η ώρα στην οθόνη του K-6100 θα σταματήσει να αναβοσβήνει .

Χρονοδιακόπτης

- 1) Πατήστε TIME ON και το TIME ON θα αρχίσει να αναβοσβήνει .
- 2) Πατήστε TIME +/- για να ρυθμίσετε την ώρα που θα ανοίγει το κλιματιστικό σας .



- 3) Πατήστε το TIME OFF και η ένδειξη TIME OFF θα αναβοσβήνει
- 4) Πατήστε το TIME + για να ρυθμίσετε την ώρα που θα κλείνει το κλιματιστικό σας .



ΣΗΜΕΙΩΣΗ :

1. Ρύθμιση ώρας - 24ώρο

2. Πατώντας συνεχόμενα το TIME ON ή το TIME OFF δυο φορές ακυρώνεται το TIME ON ή το TIME OFF

3. Αφού ρυθμίσετε το χρονοδιακόπτη πρέπει να στρέψετε το K-6100 προς το κλιματιστικό σας

Επαναφορά εργο/κες ρυθμίσεις

1. Πατήστε SELECT και FAN ταυτόχρονα .
 2. Μετά από 5 δευτερόλεπτα ο φωτισμός του K-6100 θα ενεργοποιηθεί για 1 δευτερόλεπτο .
- Τώρα το έχετε επαναφέρει στις εργοστασιακές ρυθμίσεις .



Applicable Brand and Code List

Brand	Model Code
ALPIN	、 0908529053 、 2337、 3727 1642
AIRWELL	、 0556055250、 、 1946、 2641 1251
AUCMA	、 0628-0296 、 0675、 13615-0616 、 2547、 2701、 3068、 、 3763
AUX	、 06792969200 、 1687、 2082、 2387、 、 3080、 3775、 2674
BOERKA	、 04340386-0437、 、 1827、 2468、 2779、 、 3216、 3911、 3214
CARRIER	、 020820006、 、 0564、 0565、 8883 、 1599、 1953、 2581、 、 3345、 3684、 2650
CHANGHONG	0301-0807-0619、 、 0636
CHIGO	、 05879-0382 0648-0653
CHOFU	、 8798413187、 、 3659、 3661、 2270
CHUNLAN	03459350620、 、 1040、 1184、 0787、 、 2538、 2705、 3027、 、 3417
CORONA	、 0459016854、 、 2240、 2248、 2564、 、 3635、 3636、 2944、
COMFOR STAR	0613、 1308、 2698、 3393
CONROWA	、 176872462、 3157、 、 3852
CHANGLING	、 07084 0707、 0708、 、 2097、 2791、 3399
DAIKIN	、 05651-0887、 、 0621-0625、 10683 、 1561、 3646-3688
DECODING	、 1302472037、 2732、 、 3427

Brand	Model Code
DOCTOR	、 0449022144、 1611、 、 2306、 3696、 1839
DONGBAO	035006611749、 、 2441、 2442、 2440、 3835
DONGXINBAO	、 04108、 1803、 3193、 3888、
ELECTRA	、 0557230252、 1623、 、 2642、 3337、 2708
Electrolux	、 02660221569、 0594-0598
FEDDERS	、 122028918、 3308、
FRESTECH	、 052770520、 0601、 0602、 、 0655
FUJITSU	、 0427401852、 、 0554、 0626、 0683-0682、
FUNAI	、 0481、 0470、 1871、 、 3210、 3216、 2956
GUQIAO	、 049102369、 2329、 、 3024、 3271、 2966
GALANZ	、 0521103728-0639、 0698 、 1216、 1333-1334、 1762、 、 3151、 3966 1911
GLEE	、 109398-0899、 2484
GOLDSTAR	、 04680469、 0572、 0600
GREE	、 04803095216 、 0689-0691、 069543
GAOLUHUA	、 030230457、 2454、 、 3237、 3799、 3103
HAIER	、 062726628270694、
HISENSE	、 0582-08889、 、 0632
HITACHI	、 05018-0520、 、 0665-0674
HUABAO	、 0886-0887、 1336、 、 3214、 342423429
HUAKE	、 1103、 2408 3883、
HUAMEI	、 0460-0462 1097、 1156、 、 2550、 3182、 32863245、 3877

Brand	Model Code
HUALING	、 0452-0889-0631、 、 2317-2320、 3240326 、 3927、 3795
HUIFENG	、 1065-03750、 3845、
HUIKANG	、 0441-0443、 1137、 、 3221、 382529259
HYUNDAI	、 0433-0251、 1246、 1592、 、 1941、 2287、 36823 3908、
JDC	、 0440、 1068373458、 、 3153、 3915 2525
JIANGNAN A/C	0432 1127、 2517
JINDA	、 3194、 38894
JINSONG	、 0486-0488、
JOHSON	、 0492、 02457、 1635、 、 3967、 2330
KANGLI	、 28574-03754、 3849
KELON	、 06282-0882-0643、
KLIMATAIR	02052226921、 、 3005、 3927、 1616
KOLIN	、 110216-0418 、 3198、 3891、
KONKA	、 0457-0459 1154、 、 3872 1787
LEHUA	、 0438-0439 0527、 、 0644、 0531
LG	、 0504-009740200 、 0684-0685、 08877 、 2977-2980、 32762
LIANGYU	、 045102028、 2318、 、 3708、 3231
LITTLE DUCK	0530、 0015、 0016、 0017、 0018、 、 0020、 2615、 3010、 3494、
LOREN-SEBO	、 0285、 0472、 1645、 、 3946、 2557
MACQUAY	023466237
MIDEA	、 0522000865 、 0686-0688
MINGXING	、 128590675、

Brand	Model Code
MITSUBISHI	000000479、 0547、 、 0568、 0582-08591、 0645、 、 2632、 2731 0646
NORITZ	、 3211043906
OMEGA	、 1254052644、
Panasonic National	0138-0154、 0658-0660、 0676
PANDA	、 1768-03853、
PHILCO	、 0248702490、
PROTON	042110423 、 1811、 3201、 3898、
RAYBO	、 0362032747-2452、 3842、
ROWA	、 0531、 05274、
Sabro	、 0506-0585
SAIJO DENKI	0212-0215、 1602、 2995、 3690
SAMPO	、 0424042610、 3900、
SAMSUNG	01880396 0518、 、 0680、 0684-0683、 、 2275、 2276、 22988、 2971、 、 3978、 2973
SANYO	、 0052900504、 0605、 0683、
SASUKI	、 0470020454、 0949、 1644、 、 2739、 3434、 23290、 3945
SAST	、 1328、 8633、
SHANGLING	0384-0388-0445、 2470、 、 3224、 3863、 31820、
SHANXING	、 04092 1087、 3924、
SHARP	、 0185010803、 0634、 、 3467、 0678
SHENGFENG SHUANGLU	0376、 0404-0407、 0480、 、 39551
SHINCO	、 03854346、 1049、 、 1741、 3131、 3991
SHUANGLU	04040657-0657、 1351、 2492
SONGGE	04220829904、
SOVE	、 0809-08022、 2495、 3884
SWAN	、 1914、 3624 3999

Brand	Model Code
SUMMER	、 0666042056、 3446、 3902、
SUNDURG	、 0506252342、 3037、 3285、 、 3980
TADIRAN	、 0886026841、 3031、 、 3721
TATUNG	、 2899-08895
TCL	、 0570020345280696、 2655
TECO	、 0473-04750516、 2601、
TIANDI、 MICOM	041510 、 2500、 3890
TOSHIBA	、 0498-0499、 0561、 、 1507、 1951、 2682、 2647、
TOYO	、 1309、 2094 3394、
TRANE	0227-0232、 0589
UNI-AIR	、 0422-03925
WEILI	、 0555906296
Whirlpool	、 0562-04607、 0608、 、 3977、 0702
XILENG	、 06271-06122、 3407
XINLE	、 387000-0401
YANGTZE	、 179340383、 3878、
YANGZI	、 2044、 0634、
YAOMA	、 2684、 0599、
YINYAN	、 0236602391 、 1649、 24092-0598
YORK	、 0682380883 0702、 、 2788、 3482 0703
INDIA	、 0699、 07098 0701、 0610、 、 0635、 0648、 0652、 0597、 、 0688、 0693、 0268、 0596、 、 0107、 0691、 0697、 0639、 、 0652、 0275、 02106、 0607、 、 0613、 2088、 0768、 3736、
NEC	、 0494、 0504930509、 1195、 、 3984、 1890